

CURRENT SENSORS AND CONVERTERS

Part number	Description	PM 20	PM 30	PM30plus	PM40
1ACK1	Converter current 1A:200mA			✓	✓
1ACK5	Converter current 5A:200mA			✓	✓
1ACR100S	CT 100A,15 mm Iron core (10-120A)	✓	✓	✓	✓
1ACR100	CT 100A, 52mm Iron core (10-120A),	✓	✓	✓	✓
1ACR500	CT 500A, 52mm Iron Core(50-600A)	✓	✓	✓	✓
1ACR1000	CT 1000A, 52mm Iron Core(100-1200A)	✓	✓	✓	✓
1ACF3000-6	CT 3000A, Flexible 600mm (100-3600A) [Blue]			✓	✓
1AFF3000-6	CT 3000A, Flexible 600mm, 100-3600A [Green]			✓	✓
1ACF3000-9	CT 3000A, Flexible 900mm (100-3600A) [Blue]			✓	✓

VOLTAGE LEADS AND ATTACHMENTS

Part number	Description	PM 20	PM 30	PM30plus	PM40
1APC4	Single phase power lead	✓	✓	✓	✓
1AVL3	3-Wire (Delta) voltage cable assembly to fused end	✓	✓	✓	✓
1AVL4C2	4 wire voltage lead(3P+N) fused assembly with large clamps	✓	✓	✓	✓
1AVL4	4 wire voltage lead (3P+N) assembly to fused end	✓	✓	✓	✓

1AAC4BC	Banana plug fused attachment (3P+N) with smalls clamps for 1AVL4	✓	✓	✓	✓
1AAC4TE	Tinned end fused attachment for 1AVL4	✓	✓	✓	✓
1AVL4-AC4BC	4 wire voltage lead (3P+N) fused assembly with small clamps	✓	✓	✓	✓
1AAC1NCL/BK	Black voltage large clamp lead assembly	✓	✓	✓	✓
1AAC1NCL/BU	Blue voltage large clamp lead assembly	✓	✓	✓	✓
1AAC1NCL/WH	White voltage large clamp lead assembly	✓	✓	✓	✓
1AAC1NCL/RD	Red voltage large clamp lead assembly	✓	✓	✓	✓
1AVL6	6 wire voltage lead (3P + 3N) assembly to fused end			✓	✓
1AVL6-AC6BC	6 wire voltage lead (3P + 3N) fused assembly with small clamps			✓	✓
1AAC6BC-1	Banana plug fused attachment (3P+ 3N) with smalls clamps for 1AVL4			✓	✓
1AAC6TE	Tinned end Fused attachment for 1AVL6			✓	✓
1AVL6C2	6 wire voltage lead(3P+ 3N) fused assembly with large clamps			✓	✓